

Installation Instructions

3-Way (Multi-location) **SWITCH** 15A-120/277V AC/CA

READ THESE INSTRUCTIONS **BEFORE INSTALLING**

DI-000-E5603-02C-W

Cat. No. E5603

If you need help...

www.leviton.com/support

www.leviton.com/contact



1-800-824-3005 (USA) 1-800-405-5320 (Canada)

Leviton Manufacturing Co., Inc. 201 North Service Road, Melville, NY 11747

© 2025 Leviton Manufacturing Co., Inc. All rights reserved.

Specifications subject to change at any time without notice.

SAFER, FASTER, and EASIER



Leviton's Lever Edge Switch makes it safer, faster, and easier to install a new switch.

Colored levers easily identify where to connect each wire.

There are no exposed wires or metal parts after installation.

Built-in strip gauge.

An extra large plastic strap facilitates installation in large wall openings.


Designed for midway wallplates for extra coverage, or you can easily convert it to use with standard wallplates by removing the break-off tabs.

Built-in alignment feature to align other Lever Edge products in a multi-gang installation. (See page 11.)




Terminates wire with a snap

The colored levers snap shut to terminate the wires.





The color-coded levers easily identify where to connect the wallbox wires to the switch.



NOTES:

- Wire colors in your wallbox may be different from the lever colors. See "Preparing Wires," on page 5 to make sure you insert the wires properly.
- Both Traveler 1 or 2 can be connected to either Traveler



Recommended Tools

Slotted/Phillips Screwdriver

Needle Nose Pliers




Voltage Tester

Wire Stripper










DO NOT use copper-clad wires in this device.

 Neutral wires are typically white, and may be found in the wallbox. Neutral wires are not required to operate this device.

wire only. · Ground wires may be green.

4. Label the wires, as shown.



If your wallbox looks different, contact an electrician.






Preparing Wires

1. Make sure that the ends of the wires from the wallbox are straight (cut if necessary).



2. Strip each wire in the wallbox, as shown below.




Use Strip Gauge as shown below (measure bare wire here)






NOTE: Work on only one connection at a time.

1. Fully open lever.





2. Insert the proper wire into the wire hole per the wiring diagram on page 7. Make sure the wire is fully inserted and no bare wire is exposed.


NOTE: If using stranded wire twist wire before insertion.



3. Fully close lever.







If you are unsure about these instructions, contact an electrician.


Multi-Gang Box Installation

WARNING: Turn the power OFF at the circuit breaker or fuse before you tighten the screws.

1. To install the switch next to other Lever Edge devices, use the alignment feature to easily place each device next to each other in the multi-gang box.



2. Tighten the mounting screws into wallbox.



3. Install wallplate, and restore power.

Safety First

WARNINGS:

installation.

• TO AVOID FIRE SHOCK OR DEATH; TURN OFF POWER at circuit breaker or fuse when servicing, installing or removing device.

5. To complete the installation, proceed to the next page. If you are unsure about the installation process, contact Leviton Technical Support,

or contact an electrician.

1. Position all wires so that there is room in the wallbox

3. Restore power at the circuit breaker or fuse.

4. Press the switch. If the Load turns ON,

WARNING: Turn the power OFF at the

breaker or fuse before you complete the

for the device.

2. Partially screw the mounting screws into the wallbox's mounting holes.

wiring is complete.

- . This product is to be installed and/or used in accordance with electrical codes and regulations.
- If you are unsure about any part of these instructions. consult an electrician.

CAUTIONS:

- · Use this device with solid or stranded copper wire only.
- DO NOT use this device with copper clad wire. . To avoid damage to the product, DO NOT use disinfecting products,
- including foggers, sprays or other types of atomized cleaning agents
- . DO NOT spray liquid onto the product.
- . To clean, use a damp cloth with mild soap

PATENT STATEMENT

Patents covering this product, if any, can be found on Leviton.com/patents.

Limited 2 Year Warranty & Exclusions

For Leviton's limited product warranty, go to www.leviton.com printed copy of the warranty, call 1-800-824-3005.

FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at Leviton Manufacturing of Canada ULC to the attention of the Quality Assurance Department 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9 or by telephone at 1 800 405-5320.


Scan this QR code for additional Lever Edge product information and to view the install video.





Wallplate Installation Preparation

The switch strap is designed for midway wallplates. If you want to use a standard size wallplate, carefully remove both break-off fins, as shown below.





Single-Gang Box Installation

WARNING: Turn the power OFF at the circuit breaker or fuse before you tighten the screws.

10

1. Tighten the mounting screws into wallbox.

3-Way Wiring

(continued)



2. Install wallplate, and restore power.

Visit leviton.com/support or contact Technical 11 Services at 1-800-824-3005 for additional help.